

Handleiding TE 374

A. Alarm activeren

Druk op de grote toets om het alarm te activeren. U hoort één piep om de activering te bevestigen. De LED in de auto knippert langzaam.

B. Alarm deactiveren

Druk op de grote knop om het alarm te deactiveren. U hoort twee piepen om te deactiveren. De LED in de auto knippert snel.

C. Autotracering/noodsignaal

1. Autotracering: druk de kleine toets één maal in, het systeem piept en knippert 5 keer.
2. Noodsignaal: houd de kleine toets 2 seconden lang ingedrukt. De sirene loeit en het licht knippert 30 seconden. De startonderbreker blijft ingeschakeld totdat het systeem is gedeactiveerd met de zender.

D. Instellen op afstand (Remote-Table)

1. Het systeem moet gedeactiveerd zijn.

2. De deur moet open staan (zwart/witte draad moet massa maken).

3. Draai de contactsleutel van uit naar aan (het aantal keren is afhankelijk van de instelling die u kiest).

*Voorbeeld: bij het programmeren van de handzender moet u 7 x het contact aan zetten, bij de zevende keer op contact laten staan. Als de knipperlichten dan 1 x oplichten houdt u de bovenste (grote) handzender knop ingedrukt. U laat de knop pas los als de knipperlichten 3 x hebben nageknipperd.

Let op: Tussen iedere keer dat u het contact aan en uit zet, mag maar twee seconden zitten.

4. Dus nog even kort samengevat. Als het licht een keer knippert kunt u de instelling verrichten. Druk vervolgens op de grote bovenste knop om dit te bevestigen. Als u de instelling ongedaan wil maken moet u hetzelfde weer doen maar dan moeten de knipperlichten één keer knipperen.

5. Zet de auto van contact af en doe de deur dicht. Hiermee sluit u de procedure af.

LET OP!!!! Dit systeem kan alleen op auto's met een massa gestuurd centraal deur vergrendeling systeem!

Remote-Table

Let op!! als u een programmering wilt uitvoeren moet u er zeker van zijn dat de zwart/witte draad aangesloten zit (moet massa maken) anders is een programmering niet mogelijk.

Contactsleutel Aan/uit zetten	kenmerken	knipperlicht knippert na het inhouden van de handzender 1 of 3 keer ter bevestiging	
		3 x ter bevestiging	1 x ter bevestiging
5 x	Passief alarm Dubbele Hersluiting Dubbele Reactivatie	Ja	Nee
6 x	Slot Timing	3,5 seconden	0,5 seconden
7 x	Zendercodes *Draai de contactsleutel 7 keer aan en uit, en houd de sleutel na de 7 ^e keer op de aan positie, de knipperlichten flitsen 1 keer, druk op dat moment de grote knop van de handzender één keer in, als de lampen dan 3 keer na flitsen is de handzender geprogrammeerd.		
8 x	Piepen bij (de)activeren	Met piep	Stil
9 x	Sirene	Aan	Uit
10 x	Sirene of Claxon	Sirene	Claxon

Het systeem is standaard ingesteld op 0,5 seconden sluit en open puls.

Manual TE 374

A. Activating alarm

Press the big button to activate the alarm. You will hear one beep for activation. The LED in the car will blink slowly.

B. Deactivating alarm

Press the big button to deactivate the alarm. You will hear two beeps for deactivation. The LED in the car will blink rapidly.

C. Autotracing/Emergency signal

1. Autotracing: press the small button once, the system will blink and beep 5 times.
2. Emergency signal: press the small button for 2 seconds. The sirene makes a lot of noise and the lights will blink for 30 seconds. The startinhibitor remains active untill the system is deactivated with the transmitter.

D. Remotely setting (Remote-Table)

1. The system must be deactivated.
2. The door must be opened (black/white wires must make an earth point).
3. Turn the ignition key from off to on (the number of repetitions depends on the setting you choose).

*Sample: when programming the handtransmitter you need to switch on the contact 7 times, it needs to remain on contact the 7th time. When the side-flashers then blink once keep the (big) handtransmitter button pushed. You will release the button after the side-flashers blinked 3 times.

Be aware: between switching on and off, there may not be a longer delay than 2 seconds.

4. So a small summary. When the lights blink once you can make the settings. Afterwards press the big button on top to confirm. If you want to undo the settings do the same as before but now the side-flashers need to blink once.
5. Switch the contact of and close the door. This will end the procedure.

BE AWARE!!!! This system can only be applied on cars with a mass controlled central door locking system!

Remote-Table

Be aware!! If you want to perform a programming you must be certain that the black/white cable is connected (must make mass) or else programming is not possible.

Ignition key Turn On/off	Features	Side-Flashers blink after pressing the handtransmitter 1 or 3 times for conformation	
		3 x for conformation	1 x for conformation
5 x	Passive alarm Double Reclosure Double Reactivation	Yes	No
6 x	Slot Timing	3,5 seconds	0,5 seconds
7 x	Transmittercodes *Turn the ignition key 7 times on and off, hold the ignition key on the 7 ^e time in the on position, the side-flashers will blink once, at that moment you must press the big button on the hand transmitter, the hand transmitter is programmed when the side-flashers blink 3 times after that.		
8 x	Beebs at (de)activating	With beep	Quiet
9 x	Siren	On	Off
10 x	Siren or horn	Siren	Horn

The system is standard programmed at 0,5 seconds close and open puls.

